

SPRING BOLT™

EPOXY ADHESIVE DIRECTIONS

(consulte la página 2 para español)

1. Make sure surface is clean, dry and sanded.
2. **THOROUGHLY** mix equal parts by volume of Part 1 and Part 2. Make sure glue becomes a uniform color and there is no streaking due to insufficient mix.
3. Apply glue to both surfaces to be joined. It is not necessary for glue joint to be put under pressure.
4. Glue takes 3-4 hours to set at room temperature. Complete cure time is typically 24 hours. This will vary depending on amount of glue used, ambient temperature and humidity.

(consulte la página 2 para español)

SPRING BOLT™

ADHESIVO EPOXI INSTRUCCIONES

(see page 1 for English)

1. Asegúrese que la superficie esté limpia, seca y lijada.
2. **A FONDO** mezcla partes iguales por volumen de la Parte 1 y Parte 2. Pegamento asegurese que se convierte en un color uniforme y no hay rayas, debido a la mezcla insuficiente.
3. Aplique el pegamento en ambas superficies a unir. No es necesario para el pegamento conjunta para poner bajo presión.
4. Pegue toma 3-4 horas para dar la temperatura ambiente. Tiempo de curación completa es normalmente de 24 horas. Esto variará dependiendo de la cantidad de pegamento utilizado, la temperatura ambiente y humedad.

(see page 1 for English)